

PLAN "A"



1

—————

A) Bottom of ductwork is about 15' off of floor.

B) All drops are 6" dia from main trunkline. Then reducer to 4" on the Thread rollers. For the Cold Header, one 6" drop and one 5" drop.

For the Thread rollers;

C) Use hard ductwork 4" to the hood
Use flex ductwork to the other 4" drop
540 CFM per drop

