



B

A hole pre-drilled at the bracket before shipment. Please source an eyebolt locally. Connect the carabiner with large gate opening to this eyebolt.



A

Eyebolts sent along with the hood. Please source a hook to hook: one end of the connection to the load, fall indicator; the other end to the eyebolt at the hood.

