



- Take out **Adjustable Feet.**
- Fasten Adjustable Feet to BL, BM-1~3 and BR.




- Take out **BL** and **BS-1**.
- Join **BL** and **BS-1** together with:

Part name	Description	Photos	Q'ty	Grainger Model #
Hex Screw	5/16″ x 3″	$ \begin{array}{c} 1/4" - 5/32" - 5/32" - 5/16" - 5/32" - 5/8" - 5/16" - 7/16" - 5/8" - 7/8" - 7/8" - 7/8" - 7/8" - 1-1/4" - 1-1/2" - 1-1/4" - 1-1/4" - 1-1/4" - 1-3/4" - 2-1/4" - 2-1/4" - 2-1/2" - 2-3/4" - 3" - 3" - 3" - 3" - 3" - 3" - 3" - $	2	1YU39
Flat Washer	5/16″ x OD23 x 2T	OD23	2	*1JY31




- Take out **BM-1**.
- Fasten **BM-1** to **BS-1** with:

Part name	Description	Photos	Q'ty	Grainger Model #
Hex Screw	5/16″ x 3″	$ \begin{array}{c} 1/4"5/32" -5/16" -5/16" -5/8" -5/8" -5/8" -5/8" -5/8" -5/8" -7/8" -7/8" -1-1/4" -1-1/2" -1-1/4" -1-1/4" -1-1/4" -1-3" -1-3/4" -1-3" -1-3/4" -1-3" -1-3" -1-3/4" -1-3" $	2	1YU39
Flat Washer	5/16" x OD23 x 2T	OD23	2	*1JY31



- Take out **BS-2**.
- Fasten **BS-2** to **BM-1** with:


Part name	Description	Photos	Q'ty	Grainger Model #
Hex Screw	5/16″ x 3″	$ \begin{array}{c} 1/4" \\ -5/32" \\ -5/16" \\ -5/16" \\ -7/16" \\ -5/8" \\ -7/8" \\ 1" \\ -1-1/4" \\ 1-1/2" \\ 2'' \\ 2'' \\ 2'' \\ 2'' \\ 2'' \\ 2'' \\ 2'' \\ 2'' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\$	2	1YU39
Flat Washer	5/16″ x OD23 x 2T	OD23	2	*1JY31



Page-9


- Take out **BM-2**.
- Fasten **BM-2** to **BS-2** with:

Part name	Description	Photos	Q'ty	Grainger Model #
Hex Screw	5/16″ x 3″	$ \begin{array}{c} 1/4" - 5/32" - 5/16" - 5/16" - 5/8" - 5/8" - 5/8" - 5/8" - 5/8" - 7/8" - 1-1/4" - 1-1/2" - 1-1/4" - 1-1/2" - 1-3/4" - 2-1/2" - 2-3/4" - 2-3/4" - 2-3/4" - 3" - 3" - 3" - 3" - 3" - 3" - 3" - $	2	1YU39
Flat Washer	5/16" x OD23 x 2T	OD23 (5/16")	2	*1JY31




- Take out **BS-3**.
- Fasten **BS-3** to **BM-2** with:

Part name	Description	Photos	Q'ty	Grainger Model #
Hex Screw	5/16″ x 3″	$ \begin{array}{c} 1/4" - 5/32" - 5/16" - 5/16" - 5/8" - 5/8" - 5/8" - 5/8" - 5/8" - 7/8" - 1-1/4" - 1-1/2" - 1-1/4" - 1-1/2" - 1-3/4" - 2-1/2" - 2-3/4" - 2-3/4" - 2-3/4" - 3" - 3" - 3" - 3" - 3" - 3" - 3" - $	2	1YU39
Flat Washer	5/16" x OD23 x 2T	OD23 (5/16")	2	*1JY31




**BM-2** 



Page-13


- Take out **BM-3**.
- Fasten **BM-3** to **BS-3** with:

Part name	Description	Photos	Q'ty	Grainger Model #
Hex Screw	5/16″ x 3″	$ \begin{array}{c} 1/4" - 5/32" \\ -5/16" \\ -5/16" \\ -7/16" \\ -5/8" \\ -7/8" \\ 1"5/8" \\ -7/8" \\ -1-1/4" \\ -1-1/4" \\ 2''1-3/4" \\ 2''1-3/4" \\ 2''1-3/4" \\ 3''1-3/4" \\ -2-3/4"1-3/4" \\ 3''1-3/4 \\ -3''1-3/4 \\ $	2	1YU39
Flat Washer	5/16" x OD23 x 2T	OD23	2	*1JY31




- Take out **BS-4**.
- Fasten **BS-4** to **BM-3** with:

Part name	Description	Photos	Q'ty	Grainger Model #
Hex Screw	5/16″ x 3″	$ \begin{array}{c} 1/4" \\ -5/32" \\ -5/16" \\ -5/16" \\ -7/16" \\ -5/8" \\ -7/8" \\ 1" \\ -1-1/4" \\ 1-1/2" \\ 2'' \\ 2'' \\ 2'' \\ 2'' \\ 2'' \\ 2'' \\ 2'' \\ 2'' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\ -1' \\ 3'' \\ -1' \\$	2	1YU39
Flat Washer	5/16″ x OD23 x 2T	OD23	2	*1JY31




- Take out **BR**.
- Fasten **BR** to **BS-4** with:

Part name	Description	Photos	Q'ty	Grainger Model #
Hex Screw	5/16″ x 3″	$ \begin{array}{c} 1/4" - 5/32" \\ -5/16" \\ -5/16" \\ -7/16" \\ -5/8" \\ -7/8" \\ 1"5/8" \\ -7/8" \\ -1-1/4" \\ -1-1/4" \\ 2''1-3/4" \\ 2''1-3/4" \\ 2''1-3/4" \\ 3''1-3/4" \\ -2-3/4"1-3/4" \\ 3''1-3/4 \\ -3''1-3/4 \\ $	2	1YU39
Flat Washer	5/16" x OD23 x 2T	OD23	2	*1JY31




- Take out **Working Light base**.
- Fasten Working Light base to BS-1~4 with:


Part name	Description	Photos	Q'ty	Grainger Model #
Hex Screw	1/4″ x 3/4″	1/4"	16	1UY24
Flat Washer	1/4" x OD19 x 2T	OD19	16	<b>*</b> 1JY29



- Take out **Working Light**.
- Assemble the **Working Light** to the base.




- Take out **Adjustable Feet.**
- Fasten **Adjustable Feet** to **TG**.




- Take out **TB**.
- Fasten **TG** to **TB** with:

Part name	Description	Photos	Q'ty	Grainger Model #
Flat Washer	5/16" x OD18 x 2T	OD18 (5/16")	2	*1JY31
Hex Nut	5/16″	5/16" The second	2	2FE51




• Assemble **Table** into the booth.



- Take out **A**.
- Fasten A to BL, BM-1~ BM-3 and BR with:


Part name	Description	Photos	Q'ty	Grainger Model #
Hex Screw	5/16" x 3/4"	1/4"	8	1YU33
Flat Washer	5/16" x OD23 x 2T	OD23	8	*1JY31





• Fasten **Sleeve Anchor** for legs to field bolted if needed.

Assembly completed.

Part name	Description	Photos	Qʻty	Grainger Model #
Sleeve Anchor	3/8″ x 3″	$ \begin{array}{c} 1/4" \\ 3/8" \\ 1/2 \\ 3/4" - \\ 1" - \\ 3/4" - \\ -7/8" \\ -7/8" \\ -1 - 1/4" \\ -1 - 1/4" \\ -1 - 3/4" \\ 2 - 1/2" - \\ 3" - \\ \end{array} $	36	3A475







Page-31

