

VFD Parameter Settings

model #		Functions	Factory Setting	Parameters
WB-3000 Harlingen po# 4094	1	Parameter Reset: 08: Keypad lock	08	00-02
	2	Maximum Output Frequency (Fmax)	54 Hz	01-00
	3	Maximum Voltage Frequency (Fbase)	60 Hz	01-01
	4	Maximum Output Voltage (Vmax)	460V	01-02
	5	Mid-Point Frequency (Fmid)	0.5 Hz	01-03
	6	Mid-Point Voltage (Vmid)	3.4V	01-04
	7	Minimum Output Voltage (Vmin)	3.4V	01-06
	8	Accel Time 1	15 sec	01-09
	9	Decel Time 1	15 sec	01-10
	10	Source of First Operation Command 01: External terminals. Keypad STOP/RESET enabled.	01	02-01
	11	Multi-Function Output Terminal MO3 08: Fault indication	08	03-03