


- Take out the base of air tank.
- Secure the base of air tank to the unit with:


Hardware (Screw attached to inside)				
Part name	Description	Photo	Q'ty	Grainger Model #
Hex Screw	3/8″ x 1″	1/4" — 3/8" — 1/2" — 3/4" — 1" — 1" —	4	1YU43
Flat Washer	3/8″ x OD23 x 2T	OD23 3/8"	4	*1JY33









Have not locked, is putting air tank and adjusting





- Take out the number: **AT**.
- Place **AT** on the base of air tank.



- Insert the connector into the coupling.
- Fasten the clamp.









• Fasten the coin.




• Fasten the Philips Head Screw with a screwdriver.



- Take out **U-Bolts**.
- Use **U-Bolts** to secure the air tank:




U-bolts



Release the screw which already on the U-Bolts, as red frame shown.

The base of air tank










• Take out the number: **AC**.

• Fasten **AC** to the base of air tank with:


	Hardware (Screw attached to inside)				
Part name	Description	Photo	Q'ty	Grainger Model #	
Hex Screw	3/8″ x 1″	1/4" — 3/8" — 1/2" — 3/4" — 1" — 1" — 7/16"	2	1YU43	
Hex Screw	3/8″ x 3/4″	1/4"	2	1YU42	
Flat Washer	3/8″ x OD23 x 2T	OD23 (3/8")	4	*1JY33	








- Take out the **Nipple**.
- Fasten the **Nipple** to the air tank.











- Take out the **Air Regulator**.
- Fasten the **Air Regulator** to the nipple.






lacksquare	Assemble	upper	unit to	lower	unit using :
------------	----------	-------	---------	-------	--------------

	Hardware A					
Part name	Description	Photo	Q'ty	Grainger Model #		
Hex Screw	3/8″ x 1″	1/4"	50	1YU43		
Flat Washer	3/8″ x OD23 x 2T	OD23 3/8"	100	*1JY33		
Split Lock Washer	3/8″	3/8"	50	6DYV1		

Hex Nut	3/8″	3/8" The second	50	2FE57
Rubber Washer	M12	M12	50	



Lower Unit

Upper Unit




Page.19

- Take out the number : **CQ** (Square To Round).
- Assemble CQ (Square To Round) to Blower housing

using:


	Hai	rdware D		
Part name	Description	Photo	Q'ty	Grainger Model #
Hex Screw	3/8″ x 1″	1/4"	14	1YU43
Flat Washer	3/8″ x OD23 x 2T	OD23 (3/8")	28	*1JY33
Hex Nut	3/8″	3/8" HEX NUT	14	2FE57



- Take out the **Flanged Connection.**
- Secure Flanged Connection to Square To Round


using:

• Hardware C					
Part name	Description	Photo	Q'ty	Grainger Model #	
Hex Screw	3/8″ x 1″	1/4"	12	1YU43	
Flat Washer	3/8″ x OD23 x 2T	OD23 3/8"	24	*1JY33	
Hex Nut	3/8″	3/8" () HEX NUT	12	2FE57	



• Assemble **Blower** to main unit using :


	Hardware B					
Part name	Description	Photo	Q'ty	Grainger Model #		
Hex Screw	1/2″ x 1″	1/4" 3/8" 1/2" 3/4" 1" 7/8" 7/8"	12	1YU61		
Flat Washer	1/2″ x OD25 x 2T	OD25	24	* 1JY35		
Split Lock Washer	1/2″	1/2"	12	6FYC3		
Hex Nut	1/2″	1/2" HEX NUT	12	2FE67		




- Take out the number: **HP**.
- Assemble **HP** (lower hopper) to **upper hopper** using :

	• Hardware E					
Part name	Description	Photo	Q'ty	Grainger Model #		
Hex Screw	3/8″ x 1″	1/4"	30	1YU43		
Flat Washer	3/8″ x OD23 x 2T	OD23 (3/8")	60	*1JY33		
Hex Nut	3/8″	3/8" The second	30	2FE57		

Complete Assembled







- Take out the Cartridge Collector Pulse Control Box Base.
- Assemble the Cartridge Collector Pulse Control Box Base,

Supports and Cover using :

Hardware F					
Part name	Description	Photo	Q'ty	Grainger Model #	
Hex Screw	3/8″ x 3/4″	1/4"	6	1YU42	
Flat Washer	3/8″ x OD23 x 2T	OD23 (3/8")	6	*1JY33	







Pulse Control Box Base


Pulse Control Box Base


• Fasten sleeve anchors for legs to field bolted if needed.


Part name	Description	Photos		Q'ty	Grainger Model #
Sleeve Anchor	3/4″ x 4″	1-1/2"	-1/4" -3/4"	8	2G524














5/8"