



**terminals for field electricians to run wires from blower control box here (460V / 60Hz / 3-phase) to pulse control box (120V / 60Hz / 1-phase)**

**Local main power supply for 460V / 60Hz / 3-phase**