



variable
 air field solenoids
 to run when
 from solenoid control box (480V / 60Hz / 3-phase,
 with dry type transformer)
 to pulse control box from (120V / 60Hz / 1-phase)