
cables for field electricians run wires to control box (460V / 60Hz / 1-phase)



cables for field electricians run wires from electrical junction box to electrical junction box