

Desk
16" Plenum Box
Branch 16"/12"/12"
Section X = Down Leg to each Machine
1" A
16" A
B
16"
12"
BL12
4"
D
E
F
G
H
I
10"
8"
6"
Branch 12"/7"/10"
Branch 10"/10"/10"
Branch 10"/6"/8"
Branch 8"/8"/8"
Branch 8"/5"/6"
Branch 6"/4"/4"
ODF 8000 Cell #1
doors
Header
Branch 16"/16"/16"
C
J
K
L
M
N
O
Hold Area
Drums
Ramco Washer / Dryer 8'6"x5'4"
Ramco Washer / Dryer 8'6"x5'4"
Desk
16" Plenum Box
Branch 16"/12"/12"
Section X = Down Leg to each Machine
ODF 8000 Cell #2
doors
Branch 16"/16"/16"
Oil Storage
Ramco Washer / Dryer
Ramco Washer / Dryer