



User's manual (original)

Oil mist and Oil smoke filter



- A•smoke²⁰
- A•smoke⁴⁰
- A•smoke¹²⁰

Including *Heat Treat Version*



A•smoke



Absolent

1 BASIC INFORMATION



Read and understand the user’s manual before beginning to work in the filter unit.

1.1 Introduction

In the following documentation you will find all essential information concerning safety, installation, start-up and maintenance.

This product is manufactured and designed in accordance with the EU directives that this product is embraced by.

In order to maintain this status, installation, repair and maintenance may only be carried out by qualified personnel and the use of original spare parts.

For advice regarding technical service or the need of spare parts please contact Absolent AB or your closest accredited dealer. Contact information can be found under the heading “Technical Support”.

1.2 Range of Application

The filter unit A•smoke is only designed to clean oil-contaminated* air. Other use of the filter unit is not allowed, except where the manufacturer guarantees the function. At the use of A•smoke in surroundings with graphite, plumb or chrome, more frequent service can be necessary.

*e. g. from lubricants such as emulsion, synthetic oil or/and mineral oil.

1.3 Table of Contents:

1	Basic information	2
1.1	Introduction	2
1.2	Range of Application.....	2
1.3	Table of Contents.....	2
2	Approved to CE-directives, UL and CSA standards	3
3	List of warning signes	3
4	Safety Precautions	4
5	Transport/Set up/Installation	5
5.1	General	5
5.2	Transport	5
5.3	Mounting	5
5.3.1	Putting the filter upright.....	5
6	Function / Design	6

1.3 Table of Contents, cont.

7	Technical Details	6
8	Electrical connection	7
8.1	General	7
8.2	Electrical connection of fan motor for direct start (A•smoke ²⁰ , A•smoke ^{40B}) ...	7
8.3	Electrical connection - A•smoke ⁴⁰ with control cabinet	8
8.3.1	Function of the control cabinet.....	8
8.3.2	Components of the control cabinet.....	8
8.4	Level sensor	8
8.5	Electrical connection of A•monitor	9
9	To be checked before the first start of the filter unit	10
10	Service/maintenance	11
10.1	General	11
10.2	Service schedule	11
11	Electronic manometer A•monitor (A•smoke²⁰, A•smoke⁴⁰)	12
11.1	Function	12
11.2	Pressure settings	12
12	Handling the filter cassettes	13
12.1	Weight of the filter cassettes.....	13
12.2	Instruction for replacing the filter cassettes - A•smoke ²⁰	13
12.3	Instruction for replacing the filter cassettes - A•smoke ⁴⁰ , A•smoke ¹²⁰ ...	14
12.4	Used filter cassettes	15
13	Accessories	15
13.1	Protective Motor Switch A•smoke ²⁰	15
13.2	Liquid Traps	16
13.3	Extension Frame.....	16
13.4	Transition Outlet	17
13.5	Carbon Filter Module	17
13.6	Spray System	17
13.7	Frequency converter.....	18
13.8	Prefilter for severe dirt	18
14	A•smoke⁴⁰ Heat Treat Version	19
15	Fault Tracing	20
16	Absolent warranties	21
17	Spare Parts	21
18	Technical support	21
19	EC Declaration of conformity	22


2 APPROVED TO CE-DIRECTIVES, UL AND CSA STANDARDS


The A•smoke product line is approved to:


Machine directive 2006/42/EG
 Electromagnetic Compatibility (EMC) 2004/108/EG
 Low Voltage Directive (LVD) 2006/95/EG

For the EC declaration of conformity in its entirety, see chapter 19.


All electrical components are UL approved. The electrical motor is CSA-approved.








The CSA approval is solely applicable to the electrical motor.




Absolent
 Absolent AB
 Kartåsgatan 1
 531 40 Lidköping
 Sweden
 2009-12-28



Tony Landh, CEO

3 LIST - WARNING SIGNS



Warning - Read the instructions

Read and understand the user guide before working on the filter unit.

The sign is positioned on the right-hand side of the filter unit.



Warning - Dangerous voltage

All electrical work must be carried out by qualified electricians.

The sign is located next to the control cabinet.



Warning - Tip risk

The filter unit has a high centre of gravity and with that a risk of tipping. In order to avoid personal injury, see the lifting instructions under the heading "Transport/Set up".

This sign is placed on the packaging and on the right-hand side of the filter unit.



Warning - Rotating parts

Caution - the filter unit/ and pump can be started by the timer, remote control or by a connected processing machine.

The sign is positioned on the right-hand side of the filter unit.



Warning - Risk of injury

Caution the filter unit can contain fluids dangerous to health.





Refer to the product sheet for the fluids in question before handling. The sign is positioned on the right hand side of the filter unit.



Danger - Heavy products

The filter cassettes become heavier with use. Check the current weight of the filter cassette before handling. Weight details can be found on the filter cassette's rating plate and under the heading 11 "Handling the filter cassettes".

4 SAFETY PRECAUTIONS

Type of warning	Warning text
 Danger	<p>Warning - Hazardous voltage! The filter unit works with a high electrical voltage. The electrical installation must be performed by qualified electricians. Disconnect the power supply to the filter unit before it is opened and/or before starting work on the filter unit.</p>
 Skilled personnel	<p>Warning - Do not connect the filter unit to explosive gases! Do not connect the filter unit to processing machines that can bring about an explosion risk. Furthermore, the filter unit must not be connected to media that are highly inflammable without preventative measures being taken to stop the spread of the explosion or fire to the filter unit.</p>
 Skilled personnel	<p>Caution - Read and understand the user's manual! Read and understand the user guide before working on the filter unit.</p> <p>Caution - Qualified personnel only! All work concerning transport, installation and maintenance must be performed by qualified personnel.</p>
 Risk of personal injury	<p>Risk of trapping injury! Do not insert your hand into the filter unit when the fan is running. Do not wear loosely hanging clothing near the fan when operational. These can be sucked into the fan or get caught.</p> <p>Risk of tipping over! Always check the weight of the filter unit (technical data, heading 7) before lifting. When equipped with an integrated fan assembly the centre of gravity of the filter unit is relatively high. When transporting the filter unit, secure well - an alternative can be to transport the filter unit horizontally.</p> <p>Heavy products! Filter cassettes are heavy. Check the current weight of the filter cassette before handling. Weight details can be found on the filter cassette's rating plate and under heading 12 "Handling the filter cassettes". Lifting equipment or the like must be used during service and inspection work above the ground.</p> <p>Risk of slipping! Keep the floor clean. Remove oil spill to prevent injury due to slipping.</p> <p>High noise levels! If the sound level at the control panel/workplace exceeds 75 dB(A) ear protection must be worn.</p> <p>Dangerous fluids! Use requisite personal safety equipment with all types of service work, as the filter unit can contain liquids dangerous to health. Refer to the product sheet for the liquids in question before handling.</p> <p>Caution when recirculating air back into the building! Note that in its standard design the filter unit does not separate gas molecules.</p>

5 TRANSPORT / SET UP / INSTALLATION

5.1 General

Check that the unit is undamaged on arrival and when unpacking. Contact the carrier in the event of transport damage.

5.2 Transport and delivery

The filter unit is supplied on a wooden pallet wrapped in plastic foil. Is the filter unit delivered standing up, it has a sign "Risk of tipping over" on its wrapping. The packaging should remain on the filter unit up until installation in order to prevent damage. Secure the filter firmly, or transport the filter horizontally. One of the following methods must be used when lifting:




Fig.1: Lifting the filter unit on a wooden pallet with an overhead crane.




Fig.2: Lifting the filter unit on a wooden pallet with a forklift truck.




Fig.3: Lifting a vertical filter unit using a forklift truck or overhead crane.

5.3 Set up

The filter unit must be set up on a flat and firm surface. The surface must be designed to support the weight of the filter unit. When setting up the filter unit, ducts, pipes, and electrical cables, ensure that the service doors can be opened freely (see fig. 4) and that internal components such as the filter cassettes can be removed as required.

5.3.1 Lift to the vertical position

1. Ensure that the toggle fasteners on the service doors are secured, before the filter unit is lifted to a vertical position.
2. When the filter is to be raised, fit the lifting device in the two lifting eyes, as shown in fig. 5. Carefully lift the unit as shown in fig. 6.



NB: The cords have to be long enough to form an angle of a minimum of 45° between cord and filter unit.

3. Position the filter unit in the correct position and bolt to the floor.
4. Open the door and check that the filter cassettes are properly secured, i.e. that the sealing is compressed to approx. 0.12 in / 3 mm. If a filter cassette has become loose during transport, secure them and close the service doors.
(How to secure, see heading 12.2 resp. 12.3.)
5. Connect the drainage.
6. Connect the suction pipe with a control damper. When a branch pipe is used, the recommended connection is a 30° elbow, as this gives a low pressure drop for the entire installation.
7. Connect the unit electrically (possible fan, pump and/or other accessories). Also see heading 8 "Electrical connection".




Fig.4




Fig.5




Fig.6

6 FUNCTION / DESIGN

A•smoke

Contaminated air is sucked into the inlet (1) in the lower section of the filter unit and passes through filter stage 1 (2), where the majority of the oil particles are trapped. Filter stage 1 gets saturated and the oil drops into the bottom of the filter unit, which acts as a collection container. From there, it is pumped (8) (accessory, not A•smoke²⁰) or drained away. The air passes through an additional Absolent filter (3), where the remaining bigger particles are filtered out and on via a HEPA filter (4) to the external fan. Generally the air is now free from particles and can be returned directly to the premises.

1. Inlet, pipe connection
2. Filter stage 1 (Absolent)
3. Filter stage 2 (Absolent)
4. Filter stage 3: HEPA filter
5. Fan
6. A•monitor
7. Control cabinet (Accessory, standard only for A•smoke⁴⁰)
8. Return oil tank & pump (accessory)
9. Outlet



A•smoke⁴⁰ principle

7 TECHNICAL DETAILS




		A•smoke ²⁰	A•smoke ⁴⁰	A•smoke ¹²⁰
Height, centred outlet	[in/mm]	93.5 / 2420	137.2 / 3485	145.0 / 3682
Height, side outlet	[in/mm]	-	-	154.8 / 3932
Width, excl. pump case (with pump case + 3.15 in / 80 mm)	[in/mm]	27.6 / 700	39.8 / 1010	130.5 / 3314
Depth	[in/mm]	30.7 / 780	44.3 / 1125	44.3 / 1125
Standard connection inlet	[in/mm]	Ø 7.9 / 200	Ø 12.4 / 315	Ø 19.7 / 500
Standard connection outlet	[in/mm]	-	-	Ø 24.8 / 630
Standard connection return oil	[in]	W 1 1/4"	W 3/4" ¹⁾	W 3/4" ¹⁾
Weight filter unit with dry filter cassettes	[lbs/kg]	11.8 / 300	2205 / 1000	5733 / 2600
Available dim. external pressure drop	[Pa]	430	1000	-
Filter cassettes				
Absolent filter	[pc]	2	2	6
HEPA (H13)	[pc]	1	1	3
Performance				
Max. air flow	[cfm/ m ³ /h]	1180 / 2000	2350 / 4000	7050 / 12000
Sound level (3 m in front of filter unit)	[dB/(A)]	60	67	²⁾

¹⁾ All filter units without pump have a nom. pipe size W 1 1/4" return oil connection.

²⁾ The level of sound emitted from the filter units with external fan is specified in the user's manual for the fan.

For the electrical data, see the wiring diagram in heading 8. A wiring diagram is even included in the control cabinet.

8 ELECTRICAL CONNECTION

 **Warning - Dangerous voltage**
All electrical work must be carried out by qualified electricians.


8.1 General

For the warranty to apply, a qualified person must carry out all the electrical wiring in accordance with local regulations. If the filter unit is equipped with extra electrical equipment, this equipment shall be wired according to the wiring diagram supplied. The Absolent oil mist and oil smoke filter unit can be customized to meet your needs. The range of accessories includes starting equipment and other electrical periphery equipment. The most common accessories are described under the heading "Accessories".


8.2 Electrical connection of fan motor for direct start

The Absolent filter units are standardly equipped with wired cables from the fan to the terminal blocks on the side of the filter unit.


A•smoke²⁰



A•smoke^{40B}



Electrical data can be read from the rating late on the right-hand side of the filter unit.

 **Risk of trapping injury!**
Do not insert your hand into the filter unit when the fan is running. Do not wear loosely hanging clothing near the fan when operational. These can be sucked into the fan or get caught.

8 ELECTRICAL CONNECTION (cont.)

8.3 Electrical connection of A•smoke⁴⁰ with control cabinet


The Absolent A•smoke⁴⁰ is standardly equipped with a control cabinet for fan and oil return pump. The wiring diagram is located inside the control cabinet.

For the warranty to apply, all electrical connections must be carried out by a qualified electrician and in accordance with applicable directives. If the filter unit is fitted with other electrical equipment; that equipment must be wired according to the wiring diagrams applicable to that supply.


8.3.1 Function of control cabinet - Absolent A•smoke⁴⁰

The control unit controls the fan and the oil pump.

To start the fan, set switch 1 on the outside of the door at position 1. To start the pump, set switch 2 on the outside of the door at position Aut. The pump is thereby controlled by the level sensor. To operate the pump manually, set switch 2 on the outside of the door at position 1. The LEDs in switch 1 and 2 indicate that the fan resp. pump are operating.



8.3.2 Components of control cabinet - Absolent A•smoke⁴⁰




8.4 Level sensor

The level sensor and the pump are situated on the same lid behind the blend at the lower front of the unit. The sensor has two floats with the following functions:

1. The lower float in its lowest position = pump shut off.
2. The lower float in its uppermost position = pump starts.
3. The upper float in its uppermost position = electrical signal is generated that can be used for alarm purposes, i.e. customer specific.

8 ELECTRICAL CONNECTION (cont.)

8.5 Electrical connection of A•monitor



9 TO BE CHECKED BEFORE THE FIRST START OF THE FILTER UNIT



Risk of trapping injury!

Do not insert your hand into the filter unit when the fan is running. Do not wear loosely hanging clothing near the fan when operational. These can be sucked into the fan or get caught.

1. Check that the filter cassettes are properly secured.

Open the door and check that the filter cassettes are properly secured, i.e. that the sealing is compressed to approx. 0.12 in / 3 mm. How to secure, see headings 11.2 resp. 11.3.

2. Control cabinet (A•smoke⁴⁰)

Open the lid of the control cabinet. Check that the protective motor switches for fan and pump are activated. The black buttons have to be pressed in (see photo under 8.3.2). Check that the fuses for the transformer are switched on. Switch on the power supply to the control unit by turning the safety isolating switch to position "1".

3. The fan's direction of rotation

Make sure that the fan impeller rotates in the proper direction (counter-clockwise viewed from the motor side). If you are unable to see the motor while the impeller is rotating, start the fan, read the pressure drop across the filters from the pressure gauge, stop the fan, transpose two phase leads, restart the fan and read the pressure drop again. The connection that gave the highest pressure drop is the correct one.

4. Air flow

The air flow must be checked, so that the value does not exceed the design level for the installation (refer to the quote or unless otherwise stated the nominal flow under heading "Technical data"). The air flow can be adjusted with the damper or frequency converter, if fitted. If it is difficult to reach the required flow, check the direction of rotation of the fan motor according to section 2 above. If the unit is run with a too high flow, there is a large risk that the life span of the filter cassettes will be shortened.

5. Pressure drop over the filter cassettes

A•smoke²⁰ and A•smoke⁴⁰: Read the A•monitor and note down the pressure drop over the different filter stages (heading 11). A•smoke¹²⁰: Read the analogue pressure gauges (heading 10). These values can then be used as a basic value to assess the pressure increase /life span of the different filter cassettes.

6. Return oil pump

Check that the pump starts, preferably by lifting the floats on the level sensor (see 8.4).

7. Spray system (if installed)

If the filter unit is equipped with a spray system its function must be checked as this has a large effect on the life span of the filter cassettes.

The function of the spray system and fault tracing are described in the separate user guide.


8. Frequency converter (if installed)

If the filter unit is equipped with a frequency converter, you find a protocol of the different settings and a description how to handle the frequency converter attached.

10 SERVICE / MAINTENANCE

10.1 General

Preventive maintenance and regular service extend the life span and ensure that the filter unit maintains its performance. Besides, you maintain a high cleaning efficiency in the industrial environment. To facilitate inspection of the filter cassette status, Absolent supplies the A•smoke²⁰ and A•smoke⁴⁰ filter units with an electronic pressure gauge as a standard. A•smoke¹²⁰ is supplied with 3 analogue pressure gauges for the different filter stages. The different pressure gauges are positioned on the front of the filter unit as shown below:



The pressure gauges are graduated in [Pa] and contain green, yellow and orange sectors. The filter cassette is to be replaced when its pressure gauge has reached the orange sector. The yellow sector is a warning that the filter cassette replacement is to be planned. For a service contact, see the heading “Technical Support”.

Service shall take place when the drop has reached the orange sector, for the latest. Note however, that the filter unit will not be damaged when operated with a clogged filter stage, but the required air flow will not be attained. Handling during service is described under “Changing the filter”.

More information on the electronic manometer, see heading 11.

10.2 Service schedule

Action	Monthly	Six monthly	Annually
Filter cassettes Establish filter cassette status by reading the electronic pressure gauge	X¹⁾		
Bottom section / Drainage Check that the return oil pipe is not blocked	X²⁾	X²⁾	
Fan Check that there is no abnormal noise or vibration			X

1) In order to get to know your new installation, the filter cassettes should be checked once a month during the first six months the filter unit is in use. The service interval is then adapted according to the installation in question. However, no longer than six months between inspections. Note that when the yellow LED lights, the inspection interval must be increased as the pressure drop now increases quicker.

2) In order to get to know your new installation, the bottom section and drainage should be checked once a month during the first six months the filter unit is in use. The service interval is then adapted according to the installation in question.

11 ELEKTRONIC PRESSURE MONITOR (A•smoke²⁰, A•smoke⁴⁰)

11.1 Functional description

An electronic pressure gauge A•monitor is supplied as standard along with all A•smoke filter units. The pressure monitor is delivered factory preset and contains the following features:

OPTICAL DISPLAY OVER EACH FILTER STAGE

A The present pressure drop over each filter stage is monitored (See 11.2.)

LED INDICATION


B A green LED lamp is lit as long as the filter cassette is working within the preset pressure range. When the yellow lamp is lit, call your service contact to replace the filter stage. When the red LED lamp is lit, the pressure drop is too high for the filter unit and it gives a reduced air flow.

HOUR COUNTER DEVICE

C An hour-counter device is also included in our standard equipment. It measures and monitors the operation time in hours for the filter unit.

ALARM

D On the transformer card, there is an alarm output that can be used for external alarms (maximum 1A). If any of the filter stages reaches alarm level (red LED), the alarm output closes, see 8.5)



11.2 Pressure settings

Type		Green [Pa]	Yellow [Pa]	Red [Pa]
A•smoke ²⁰	Filter 3 (HEPA)	0-600	600-800	> 800
	Filter 2 (S3B3)	0-800	800-1000	> 1000
	Filter 1 (S1)	0-1000	1000-1500	> 1500
A•smoke ⁴⁰	Filter 3 (HEPA)	0-800	800-1000	> 1000
	Filter 2 (S10B3)	0-2300	2300-2500	> 2500
	Filter 1 (S1)	0-2300	2300-2500	> 2500
A•smoke ⁴⁰ Heat Treat version	Filter 3 (HEPA)	0-800	800-1000	> 1000
	Filter 2 (M94)	0-2300	2300-2500	> 2500
	Filter 1 (D44)	0-2300	2300-2500	> 2500

PLEASE NOTE!

If a filter stage is used even though the red LED-lamp is lit, the filter unit gives a reduced air volume. Note however, that the filter unit will not be damaged when operated with a clogged filter stage. Handling during service is described under “Changing the filter”.

12 HANDLING THE FILTER CASSETTES



Warning!

Use requisite personal protection equipment when performing service work on the filter unit.
Lifts or the like must be used when carrying out service work above the ground.

12.1 Weight of the filter cassettes

Filter cassettes are heavy, especially when filled with fluid after a period of use. Below is a table of weight for the different filter cassettes available. The type designation of the supplied filter cassette can be found on the rating plate located on the front of the filter cassette.

Filter type	Filter cassette type	Weight new cassette (dry)	Weight fluid filled cassette
A•smoke ²⁰	Stage 3: HEPA TRSA-N 990 595x292	26 lb / 12 kg	35 lb / 16 kg
	Stage 2: S3B3/650	55 lb / 25 kg	110 lb / 50 kg
	Stage 1: S1/650	176 lb / 80 kg	265 lb / 120 kg
A•smoke ⁴⁰ and A•smoke ¹²⁰	Stage 3: HEPA TRSA 1D-N 1000x914	60 lb / 27 kg	82 lb / 37 kg
	Stage 2: S10B3/914 alt S10/914 resp. M44 (Heat Treat version)	342 lb / 155 kg	463 lb / 210 kg
	Stage 1: S1/914 resp. D94 (Heat Treat version)	342 lb / 155 kg	463 lb / 210 kg

12.2 Instruction for replacing the filter cassettes - A•smoke²⁰

1. Read the electronic manometer A•monitor and note down the pressure drop over the different filter stages when the filter unit is in operation. The filter cassettes whose LEDs light in yellow or red have to be replaced.
2. Shut down the fan and disconnect the filter unit from electricity.
3. Open the service door.
4. Loosen the cassette by releasing the two bolts (fig. 1).
5. Lift out the filter cassettes (fig. 2) that show a pressure drop which exceeds the service level according to "Care and maintenance". When replacing Filter stage 1, check and remove any dirt from the bottom of the filter unit.
6. Check that the sealing strip is undamaged before the new filter cassette is slid in (fig. 3). The sealing strip must be seated upward.
7. Secure the filter cassette (fig. 4).
8. Connect the filter unit to electricity
9. Start the fan and check the pressure drop.



Fig.1





Fig.2



Fig.3



Fig.4



12 HANDLING THE FILTER CASSETTES cont.

12.3 Instruction for replacing the filter cassettes - A•smoke⁴⁰ and A•smoke¹²⁰

1. Read the electronic manometer A•monitor and note down the pressure drop over the different filter stages when the filter unit is in operation. The filter cassettes whose LEDs light in yellow or red have to be replaced.
2. Shut down the fan.
3. Disconnect the filter unit from electricity.
4. Open the service door.
5. Loosen the cassette by releasing the two bolts (fig. 1).

6.1 Filter stage 1 and 2

Withdraw the filter cassette with the aid of the Absolent filter sledge (accessory) or a pallet and forklift, view fig. 2. Be careful, as the filter cassette is very heavy and possibly slippery with oil!



6.2 Filter stage 3 (HEPA-filter)

Withdraw the filter cassette.

7. Lift the new filter cassette up with the sealing strip upward and check that the sealing strip is undamaged.
8. Push it all the way into the filter housing (view fig. 3).
9. Secure the filter cassette by tightening the two bolts (fig. 4). The filter cassette is to be tightened until the sealing strip is compressed to a thickness of about 0.12 inches / 3 mm.
10. Connect the filter unit to electricity.
11. Start the fan and check the pressure drop reading for all three filter cassettes. The pressure gauges should now be in the green sector.

Note! If the supply air has a high content of chips or shavings, inspect and clean the drain opening upstream of the return oil tank/pump more often to prevent it from becoming clogged.

Fig.1



Fig.2




Fig.3




Fig.4



12.4 Worn out filter cassettes

When the filter cassette is worn out it has to be taken care of in an environmental-friendly way. The sheet metal casing and the aluminum separators can be recycled.


Clean filtermedia can be sent to disposal facilities, but when it contains oil and particles from the process, local regulations for disposal or incineration need to be followed.

If the oil is washed from the cassette, it can usually be sent for landfill.


13 ACCESSORIES

A variety of accessories are available for the Absolent type A•smoke oil mist and oil smoke filter unit. Instructions for installing these are provided on the next pages. However keep in mind that these products must be ordered separately from us if they are to be included in the delivery.

13.1 PROTECTIVE MOTOR SWITCH - A•smoke²⁰

 **Dangerous voltage**
All electrical work must be carried out by qualified electricians.

Wiring diagram for the Protective Motor Switch of the A•smoke²⁰



Fan motor:
(US) 3.5 hp, 4,6 A (440V, 60Hz)
(CA) 2.6 kW, 4,6 A (440V, 60Hz)

13.2 LIQUID TRAPS

Liquid Trap

The liquid trap is designed for connection to the return oil pipe of the filter unit. The outlet of the liquid trap should not discharge in such a way that the liquid can damage adjacent building components. Correct installation of the liquid trap is very important due to the normal sub-atmospheric pressure inside the filter unit. If you use the liquid trap, the filter unit is to be placed on an extension frame (13.4) or a mezzanine.



Liquid Trap Receptacle for A•smoke²⁰

The liquid trap receptacle is designed for connection to the return oil pipe of the filter unit.

Liquid trap receptacle consists of a drain pipe with elbow for connection to the filter unit and a tight translucent receptacle, enabling the operator to see the level of liquid inside it. Correct installation of the liquid trap is very important due to the normal sub-atmospheric pressure inside the filter unit.




13.3 EXTENSION FRAME

Extension frame - A•smoke⁴⁰

The extension frame is designed for raising the filter unit above ground level, for example for using a liquid trap.

Height: 27.6 in / 700 mm.



Extension legs - A•smoke²⁰


The extension frame is designed for raising the filter unit above ground level, for example for using the liquid trap receptacle.

Height: 15.7 in / 400 mm.



13.4 TRANSITION OUTLET

Transition outlet - A•smoke²⁰




Transition outlet - A•smoke⁴⁰

The outlet cover is designed for channel interphase.

Demount the lifting lugs, glue on the sealing strip, place the cover on top of the filter unit and screw it on with the enclosed threaded bolts. Remount the lifting lugs.

Outlet diameter 15.7 in / 400 mm.




13.5 CARBON FILTER MODULE - A•smoke⁴⁰

Carbon filter module with 4 carbon cassettes for collection of gases. For mounting, remove the mounting eyes on top of the filter unit, glue the sealing strip onto the top and place the carbon filter box onto the A•smoke unit. Secure with the enclosed bolts.

The standard carbon filter cassettes (type AFK) contain 74 lbs / 34 kg of adsorbent (filter media) each, this makes a total of 300 lbs / 136 kg.

Absolent can offer coal filter cassetts with other adsorbents that might be more effective for the actual application's specific smell or gas problem. The cassette can be refilled with new adsorbent when the old is used up. Outlet diameter: 19.7 in / 500 mm.



Regarding a carbon filter for A•smoke²⁰, please contact Absolent.

Subject to alteration without prior notice.

13.6 SPRAY SYSTEM

If the contamination is "too dry" or contains liquid particles with too high viscosity (gooey), the self-cleaning capacity of the filter degrades and the life cycle decreases drastically. To increase the liquid content and / or decrease the viscosity, little drops of liquid are added to the air through a nozzle. The added liquid has to be able to dissolve the contamination. For emulsions, use water. The nozzle is mounted onto the inlet channel. The spray system is controlled by a time relay with adjustable pause and spray time. For further information about installation, safety and service, see the user's manual for the spray system.



13.7 FREQUENCY CONVERTER

The A•smoke filter unit can be equipped with a frequency converter and a pressure sensor. Please contact Absolent / your Absolent representative for more information.




13.8 PREFILTER FOR SEVERE DIRT

For severe dirt, we supply a flat prefilter which is to be mounted under the first filter stage of the A•smoke filter unit. Please contact Absolent / your Absolent representative for more information.



14 *A•smoke⁴⁰ Heat Treat version*

A•smoke⁴⁰ Heat Treat version is the first filter unit in a series of filter units which have been optimized for different applications.



15 FAULT TRACING

Malfunction	Possible cause	Action
Low capacity (air flow)	The fan rotates in the wrong direction.	Check the fan's direction of rotation (heading 8.3) - (only skilled personnel) .
	With speed (rpm) regulation: The fan speed (rpm) is set too low.	Check the fan speed (rpm) - (only skilled personnel) .
	Too high pressure drop over one or more filter cassettes.	Check the pressure drop. If the yellow or red LED lamp is lit for one of the filter stages, the cassette should be replaced.
	High pressure drop in the duct system.	Check and possibly change the duct system
	Adjustable damper is closed or incorrectly adjusted.	Check and possibly adjust the damper on the suction pipe between the machine and filter.
	The ducts are not sealed or dirty.	Check that there is no leakage from the suction pipe between the machine and filter. Check that the ducts don't contain dirt.
Abnormally short replacement interval for the HEPA filter:	An incorrectly positioned or damaged sealing strip can result in leakage past filter stages 1, 2. Resulting in unfiltered air reaching the HEPA filter.	Check that filter stages 1, 2 are fitted with the seal upward. Also check that the sealing strip is undamaged.
	Cassettes that are not secured can result in air leakage past the filter cassettes. Unfiltered air will then reached the HEPA filter.	Check that filter stages 1, 2 are secured against the sealing frame correctly (heading 11).
	The filter cassette in stage 1 and/or 2 are not optimised for the application in question.	Check with Absolent that the correct filter cassette is being used in filter stage 1, 2 for the application in question.
Abnormally short service interval for the prefilter:	The filter cassette in stage 1 and/or 2 are not optimised for the application in question.	Check with Absolent that the correct field cassette is being used in filter stage 1 and/or 2 for the application in question.
	The filter cassettes have become clogged on account of high viscosity in the oil mist, which gives insufficient drainage.	If emulsions are used, filter clogging may be due to the filter running when production has stopped, which dries out the filter cassette (water evaporates). Consequently, switch off the filter unit when not in use. If the fluid in the process has a high viscosity, it is necessary to apply fluid with a spray system (heading 12).
	The filter cassettes have become clogged.	Check that chips have not been drawn down with the air into the filter unit. The problem with chips can be solved by calibrating the air flow or coarse filtering before the filter unit. Also check that sticky particles have not clogged filter stage no. 1 (for example, in foundry applications). Contact Absolent for appropriate measures.

16 ABSOLENT WARRANTIES

Absolent always take full responsibility that the delivered product fulfils the function and life time guaranteed when purchased. This warranty is however only valid if the product is in its original configuration and only when original spare parts have been used when servicing or repairing the filter unit.

Some examples on why original parts are so important are shown below:

1. FAN MOTOR

In order to cope with the special assembly configuration in an Absolent unit the original motor is supplied with special bearings and a bearing locking device.

Using the "wrong" type of motor will increase the risk of breakdown or failure.

2. FILTER CASSETTES

The Absolent oil mist filter depends on the multi-stage filtration technology. In order to reach the optimum filtration efficiency and the longest possible life time, the filter cassettes have been carefully balanced against each other. If one or several of these cassettes are replaced by a filter cassette this balance is destroyed and the consequence is decreased collecting efficiency and shortened life time for all filter stages.

17 SPARE PARTS

Absolent has a complete range of spare parts, which ensure the operation of installations.

Please supply the filter unit's serial number and the part number in order to guarantee delivery of the correct spare parts. These can be found on the machine plate, which is located on the right-hand side of the unit. See figure 1.

When ordering filter cassettes, the above details should be supplemented with the filter cassette's material code. This can be read on the filter cassette's rating plate by "type". See figure 2.

Absolent AB Kartåsgatan 1 SE-531 40 Lidköping, Sweden Phone +46 510484000, Fax +46 510484029		
Art.nr. Part No.		
Art.nr. Description		
Bezeichnung Bezeichnung		
Seriennr. Serial no.		CE
Seriennr. Serial no.		
Spänning Rated Voltage		(V)
Nennspannung		
Frekvens Frequency		(Hz)
Frequenz		
Märkström Rated Current		(A)
Nennstrom		
Effekt Rated output load		(kW)
Nennleistung		
Cos φ		(-)

Fig. 1

Absolent AB		Airflow
type.	S3B1/595	↑
art.no.	92110603	

Fig. 2

18 TECHNICAL SUPPORT

Absolent has a complete range of spare parts, which give full service, and ensure the operation of installations. In the event of questions concerning maintenance and spare parts please contact:

Head Office
Absolent AB
Kartåsgatan 1
SE-531 40 Lidköping
Sweden
Tel +46 (0)510 484000
Fax +46 (0)510 484029
E-mail: info@absolent.se
www.absolent.com

Dealer:

19 EC DECLARATION OF CONFORMITY

Manufacturer:

Absolent AB
Kartåsgatan 1
SE-531 40 Lidköping
Sweden
Phone: +46 (0)510-48 40 00

Authorized to compile technical documentation

Jan Berntsson
Kartåsgatan 1
SE-531 40 Lidköping
Sweden
Phone: +46 (0)510-48 40 00

We, Absolent AB, declare under our sole responsibility that the product:

A•smoke


to which this declaration relates, is in conformity with the following standard(s) or other normative document(s)

Machinery directive 2006/42/EG

Electromagnetic Compatibility (EMC)2004/108/EG

Low Voltage Directive (LVD) 2006/95/EG

Lidköping , 28th of December 2009



Tony Landh