


DDR-2000S for Hydromat

Parts Table	
1	7" Plenum Box Optional
Standard is a 90 deg elbow	
2	7" 90 Degree Elbow
3	7" Adjustable Sleeve
4	7" Pipe
5	7" Cut Pipe
6	7" Butterfly Valve
6	7" Angle flange adaptor



Notes:

- 1) All clamps need to have a bead of silicone added to the sealing area (only needed for the Nordfab system).
- 2) All adjustable sleeves in the vertical position are to be below the cut pipe.
- 3) D-ringed go on the cut pipe and a bead of silicone needs to be placed between the D-ring and the sleeve.
- 4) At points "A" Silicone angle flange adaptor to the Machine.
- 5) At point "B" Silicone Plenum Box to the Absolent.
- 6) At point "C" ensure that the cover plate is installed on the inside of the Absolent with Silicone and the screws installed from the outside into the cover plate.

Avani Environmental
 95 Cypress Drive 27596
 Youngsville, NC
 # 919-570-2862 F# 919-570-2863

Avani

Project: Hydromat DDR2000S
 Drawing: Ductwork layout
 Date: 10/3/11 Drawn by: RAV
 Sheet No: 1 of 1 Rev: 0